


Assembly

The protection sleeve of the shield must be taken apart before cover assembly.



Keep the shield upright, be careful and gentle during transportation.